
Setting up AD Server & Onboarding New User account.

Below is a step-by-step breakdown that follows the screenshot(s) captured during the setup process: (Azure VM Server 2019 *AD DS*, and Azure VM Windows 10 2019 *Client*


1. Open Server Manager on the VM Server

o Launch Server Manager from the taskbar or Start menu.




2. Add Roles and Features

- o Navigate to Manage > Add Roles and Features.
- Select Active Directory Domain Services to begin the setup.




3. Promote Server to a Domain Controller


o After installation, click the flag icon in Server Manager.



• Choose **Promote this server to a domain controller**.




Select Add a new forest, and enter
 (YOUR_PREFERRED_DOMAIN) ***example corp.local



*Once complete. Open Powershell or CMD line.


4. Install RSAT: DNS Server Tools

- Via PowerShell or Server Manager, install using:
- o Install-WindowsFeature RSAT-DNS-Server




5. DNS Verification via nslookup

- o On the DC, run:
- o nslookup
- o (YOUR_DC_SERVER_ADDRESS) should return as the Default Server address.



6. Create New User in Active Directory

- o Open Active Directory Users and Computers (ADUC).
- o Right-click your domain > New > User.
- Complete user creation and assign password. (Strong Passwords only, must comply with current password policy**



7. Create VM Client + Client VM Connectivity Verification

- o Make sure the client VM is in the same virtual network and subnet.
- On the Windows 10 client: Ensure the DNS is manually set to (YOUR_DC_SERVER_ADDRESS)

Configure DNS on Windows 10 Client

-Open Network Settings

- o Right-click the **Network icon** in the taskbar.
- o Click Open Network & Internet settings.

-Open Adapter Options

o Scroll down and click Change adapter options.

-Modify Adapter Settings

- o Right-click the active network connection (typically "Ethernet").
- o Choose **Properties**.

-Configure IPv4 DNS

- o Scroll and select Internet Protocol Version 4 (TCP/IPv4).
- o Click Properties.
- o Select Use the following DNS server addresses:
 - Preferred DNS server: (YOUR DC SERVER ADDRESS)
 - Leave alternate DNS blank or add a secondary if available.

-Apply Changes

- o Click **OK** to close each dialog.
- o Restart the adapter (disable/enable) or restart the VM if needed.

8. Network Check

- o Run:
- o ping (YOUR_DC_SERVER_ADDRESS)
 o nslookup (YOUR_DOMAIN)
- o Confirm the domain resolves and DC responds.

